


Toner Container Replacement

CS 2552ci, 3252ci, 3552ci, 4052ci, 5052ci, 6052ci


CS 4002i, CS 5002i, CS 6002i

Open the front cover.




The cover of the empty toner container is open.

Remove the toner container.



If Black Toner is empty this is a good time to replace your Waste Toner even if it's not full. See below how to replace.


Shake the toner container.




Install the toner container.

✔ **IMPORTANT**

Insert the toner container all the way.



Close the toner container cover.



Close the front cover.

